

Electrodialysis: an overview on some industrial applications

Patrick Altmeier, Henning Bolz

PCCell GmbH
Lebacher Str. 60
66265 Heusweiler, Germany
Phone +49 6806 603730
Fax +49 6806 603731
altmeier@electrodialysis.de

פרשת האים

מדיניות ■ סביבה ■ התפלה ■ טכנולוגיה
24.3.14, כפר המכביה, רמת גן


www.israelwater.org.il/conference2014

SPONSORED BY THE



Federal Ministry
of Education
and Research

Electrodialysis vs. Reverse Osmosis



- ions move, solution stay
- concentrate „pure“
- uncharged material in diluate
- concentration electrically driven

- water moves, ions stay
- diluate is „pure“
- undesired material in retentate
- concentration by pressure difference

Case 1: MgSO₄ Spa Water Management


- No effluent draining off possible
- MgSO₄ loss in spa need to be reduced
- RO not capable to achieve sufficient concentration level

Solution

- Feed circles between ED (high concentrate production) and RO (pure water production)

How ions move in ED stack

(and how water accompany ions)




K Cation Exchange Membrane blocks anions lets cations through
 A Anion Exchange Membrane blocks cations lets anions through
 Ions move through membrane – with hydrate shell
 – with additional water

Electroosmotic flow of water with chloride and sodium ions

Open membranes
(for large ions)

Standard

High crosslinked
(acidblocker)





Result:

- Ionic transfer coupled with water transfer.
- Maximum concentration obtainable depends on membrane (in MgSO_4 -case concentrations range from 14-20%)

Salt removal during batch desalination

$$i = \text{const} = 0,4 \text{ kA/m}^2$$




- constant current transfer constant amount of MgSO_4 .
- The water co-transfer reduces diluate volume → concentration drops down faster and faster.

Case 2: Fe/HCl Scrubber Rinse Water Recycling

- Water reuse / disposal criteria: $< 1 \text{ g/L Cl}^-$
- Iron salts need to be removed because of chloride criteria


Solution

- electro dialysis with multivalent ion permeation and acidblocker anion exchange membranes
- Excess acid reconcentration with monovalent selective membranes



HCl removal from FeCl₂/HCl mixture

Pure acid removal with monovalent selective membranes:
 Conductivity in diluate and concentrate over time in a batch run with



Concentrate shape if multivalent selective membranes are used



Feed composition
 Ca 0.8 g/L FeCl₂
 Ca 0.3 g/L HCl



Case 3: CIP Water Handling


- Concentrate volume reduction to 300 L/h for evaporator
- Hardness in concentrate critical, CaCO_3 transfer into concentrate to be minimised

Solution

- electrodialysis with monovalent ion permeation
- Pre-concentration with RO


CIP waste rinsing water handling

(high HCO_3^- -containing water)





Example of a batch electro dialysis desalination kinetic

www.pccell.de




Conductivity during a batch desalination





Comparison of the conductivity at inlet and outlet of the cell



Thank you very much for your attention.

Any questions?

SPONSORED BY THE



Federal Ministry
of Education
and Research